

Recycling Frequently Asked Questions

Question: Why should I recycle my computer hardware and peripherals?

Answer: Computer hardware and peripherals should be recycled for two primary reasons:

1. The materials in the products can be re-used in the production of new products, minimizing the amount of material that goes into landfills and the need for raw materials.
2. Some of the component materials must be disposed of or re-used in a specific manner to protect the environment.

Question: What do I do with the data on my hard drive?

Answer: Before you recycle or donate your product, you will need to back up any necessary data and remove all data from your hard drive. You are responsible for the deletion of all data that may be contained with the computer hardware.

Computer Place can help you do data cleanse at no cost to you if you are donating your old computer to us for re-use.

Question: Does Computer Place encourage its customers to recycle?

Answer: Yes. In our workshop and on-site support, Computer Place customers are challenged to identify solutions that reduce waste and increase recycling.

Question: Does Computer Place recycle its IT equipments?

Answer: Yes. We send our IT equipments to authorised recycling companies.

Finding new homes for old computers

Computer Place can help you do data cleanse at no cost to you if you are donating your old computer to us for re-use.

To arrange a collection from your home or business premises please contact

Computer Place

Telephone: 020 7100 3555

Or Text Us: 079 460 22 777

Both businesses and residents are welcome to drop their computers at the address below:

Computer Place

106 Golders Green Road

London NW11 8HB

Note: *We accept only working laptops, desktop pc, flat screen monitors and Mac laptops.*

(Please contact us before delivering your items)
